

CANopen Master API for Windows

Software version 1.2

Revision history

Version	Revised Date	Author	Description
1.2	2015/10/13	Rocky	Added SYNC function content Added TIME function content Added AX_SYNC_Enable function Added AX_SYNC_Disable function Added AX_SYNC_SetConfig function Added AX_SYNC_GetConfig function Added AX_TIME_Enable function Added AX_TIME_Disable function Added AX_TIME_SetConfig function Added AX_TIME_GetConfig function Added AX_PDO_GetUpdObj function Added AX_EVT_ERROR to event list Added AX_ERR_THREADFAIL to error list Added AX_ERR_EVENT_SYNC to error list Added AX_ERR_EVENT_PDO to error list Added AX_ERR_EVENT_TIME to error list Modified the parameter of AX_PDO_AddObj function Modified the parameter of AX_PDO_DelObj function Modified the parameter of AX_PDO_GetObj function Modified the parameter of AX_PDO_SetObj function Modified the maximum value of PDO No to 16. Modified the parameter of RPDO event
1.1	2015/09/16	Rocky	Added AX_ERR_PDO_CANIDEXIST in error list. Added AX_ERR_SDO_ABORT in error list. Added AX_ERR_SDO_FORMAT in error list Modified the maximum value of PDO number to 512. Modified the parameter of all PDO function. Modified the parameter of all SDO function. Modified the parameter of event.
1.0	2015/08/03	Rocky	- 1 st release

Table of contents

1 Introduction

- 1.1 Features
- 1.2 Basic specifications
- 1.3 Support CANbus board
- 1.4 Communication reference model
- 1.5 Architecture
- 1.6 Device states flow
- 1.7 Device states and communication objects

2 Basic control function

- 2.1 AX_GetLastError
- 2.2 AX_SetFunTimeout
- 2.3 AX_Open
- 2.4 AX_OpenEx
- 2.5 AX_IsOpen
- 2.6 AX_Close

3 CANBus information function

- 3.1 AX_GetModel
- 3.2 AX_GetUUID
- 3.3 AX_GetSN
- 3.4 AX_GetManufacturer
- 3.5 AX_GetProductionDate
- 3.6 AX_GetVersion

4 CANopen basic function

- 4.1 AX_SetCommTimeout
- 4.2 AX_InitCANopen
- 4.3 AX_ReleaseCANopen
- 4.4 AX_IsInitCANopen
- 4.5 AX_SetEventCallback

5 CANopen NMT function

- 5.1 AX_NMT_SearchNode
- 5.2 AX_NMT_AddNode
- 5.3 AX_NMT_DelNode

- 5.4 AX_NMT_GetNodeInfo
- 5.5 AX_NMT_GetNodeState
- 5.6 AX_NMT_StartNode
- 5.7 AX_NMT_StopNode
- 5.8 AX_NMT_EnterPreOper
- 5.9 AX_NMT_ResetComm
- 5.10 AX_NMT_ResetNode

6 CANopen SDO function

- 6.1 AX_SDO_GetObj
- 6.2 AX_SDO_SetObj

7 CANopen PDO function

- 7.1 AX_PDO_AddObj
- 7.2 AX_PDO_DelObj
- 7.3 AX_PDO_GetObjInfo
- 7.4 AX_PDO_GetUpdObj
- 7.5 AX_PDO_GetObj
- 7.6 AX_PDO_SetObj

8 CANopen SYNC function

- 8.1 AX_SYNC_Enable
- 8.2 AX_SYNC_Disable
- 8.3 AX_SYNC_SetConfig
- 8.4 AX_SYNC_GetConfig

9 CANopen TIME function

- 9.1 AX_TIME_Enable
- 9.2 AX_TIME_Disable
- 9.3 AX_TIME_SetConfig
- 9.4 AX_TIME_GetConfig

10 CANopen EMCY function

- 10.1 AX_EMCY_GetObj

11 Typical sequence of function calls

12 Appendix

12.1 Appendix - Error code list

12.2 Appendix - CANbus bitrate list

12.3 Appendix - Event list

12.4 Appendix - Monitoring type list of NMT

12.5 Appendix - CANID list for Master of NMT

12.6 Appendix - Status list of NMT

12.7 Appendix - Transmission type list of PDO

12.8 Appendix - Synchronous type list of PDO

12.9 Appendix - Transmission protocol list of SDO

1. Introduction

The CANopen Master Application Programming Interface (API) is a programming library for connecting to CANopen network in from of a single monolithic file named CANopenMasterAPI.dll.

1.1. API supported

Windows 8 32-bit/64-bit

Windows 7 32-bit/64-bit

Windows Vista 32-bit/64-bit

Windows XP 32-bit/64-bit

1.2. Basic specifications

CiA301 CANopen application layer and communication profile

1.3. Support CANbus board

The CANopen Master API primarily works together with so-called active CANbus board. There are supported CANopen Master API such as the following list of the CANbus board.

Board	Interface	Note
AX93700-CS	COM to CAN	Module
AX93700-CU	USB to CAN	Module
iCON101-CS	COM to CAN	Device
iCON101-CU	USB to CAN	Device
AX92903	USB to CAN	Mini-card

1.4. Communication reference model

The communication concept conforms to the ISO-OSI reference model.


Application layer	CANopen application layer
Presentation layer	
Session layer	
Transport layer	
Network layer	
Data link layer	CANbus physical layer
Physical layer	

1.5. Architecture

CANopen Master overview.


The below figure shows an overview of the CANopen Master functionality.

The functionality of the different CANopen services can be configured individually in order to achieve an optimal performance for different platforms and applications.



1.6. Device states flow

The state diagram of a CANopen device is specified. CANopen devices enter the state Pre-operational directly after finishing the CANopen devices initialization. During this state CANopen device parameterization and CAN-ID-allocation via SDO is possible. Then the CANopen devices may be switched directly into the state Operational. The state determines the behavior of the communication function unit.



Reset application:

In this sub-state the parameters of the manufacturer-specific profile area and of the standardized device profile area are set to their power-on values. After setting of the power-on values the sub-state reset communication is entered autonomously.

Reset communication:

In this sub-state the parameters of the communication profile area are set to their power-on values. After this the state Initialisation is finished and the CANopen device executes the service boot-up write and enters the state Pre-operational.

Pre-Operational

In the state Pre-operational, communication via SDOs is possible. PDOs do not exist, so PDO communication is not allowed. Configuration of PDOs, parameters and also the allocation of application objects (PDO mapping) may be performed by a configuration

application. The CANopen device may be switched into the state Operational directly by sending the NMT service start remote node or by means of local control.

Operational:

In the state Operational all communication objects are active. Transitioning to the state Operational creates all PDOs; the constructor uses the parameters as described in the object dictionary. Object dictionary access via SDO is possible. Implementation aspects or the application state machine however may require to limit the access to certain objects whilst being in the state Operational, e.g. an object may contain the application program which cannot be changed during execution.

Stopped:

By switching a CANopen device into the state Stopped it is forced to stop the communication altogether (except node guarding and heartbeat, if active). Furthermore, this state may be used to achieve certain application behavior. The definition of this behavior falls into the scope of device profiles and application profiles.

If there are EMCY messages triggered in this state they are pending. The most recent active EMCY reason may be transmitted after the CANopen device transits into another state.

1.7. Device states and communication objects

The below table specifies the relation between states and communication objects. Services on the listed communication objects may only be executed if the CANopen devices involved in the communication are in the appropriate states.

	Pre-operational	Operational	Stopped
PDO function		X	
SDO function	X	X	
SYNC function	X	X	
TIME function	X	X	
EMCY function	X	X	
NMT control NMT error control	X	X	X

(X:Support)

2. CANBus control function

2.1. AX_GetLastError

Summary

Get last error of CANopen API.

Definition

```
int AX_GetLastError(void)
```

Parameters

None

Return value

Error code. ([see 10.1](#))

Example

```
BOOL bRst;  
int iErr;  
iErr = AX_GetLastError();  
if (iErr != AX_ERR_NONE)  
{  
    printf("Error code = %d\r\n", iErr);  
}
```

2.2. AX_SetFunTimeout

Summary

Set timeout of function of API.

Definition

```
int AX_SetFunTimeout(DWORD iTimeout)
```

Parameters

iTimeout in timeout of function (ms)

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;
```

```
bRst = AX_SetFunTimeout(100); // 100ms
```

```
if (bRst)
```

```
{ // success
```

```
    printf("set timeout success\r\n");
```

```
}
```

```
else
```

```
{ // failure
```

```
    printf("set timeout failure (0x%X)\r\n", AX_GetLastError());
```

```
}
```

2.3. AX_Open

Summary

Open serial port of CAN-board by auto-search.

Definition

BOOL AX_Open(void)

Parameters

None

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;
bRst = AX_Open();
if (bRst)
{
    // success
    printf("open success\r\n");
}
else
{
    // failure
    printf("open failure (0x%X)\r\n", AX_GetLastError());
}
```

2.4. AX_OpenEx

Summary

Open serial port of CAN-board.

Definition

BOOL AX_OpenEx(char* pSerial, int iBaudrate)

Parameters

pSerial	in	Name of serial port
iBaudrate	in	Baudrate of serial port

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;
bRst = AX_OpenEx("COM3", 115200);
if (bRst)
{
    //success
    printf("open success\r\n");
}
else
{
    //failure
    printf("open failure (0x%X)\r\n", AX_GetLastError());
}
```

2.5. AX_IsOpen

Summary

Gets a value indicating the open or closed status of the serial port.

Definition

BOOL AX_IsOpen(void)

Parameters

None

Return value

TRUE means the device is opened, FALSE means the device is closed.

Example

```
BOOL bRst;
```

```
bRst = AX_IsOpen();
```

```
if (bRst)
```

```
{    //opened  
    printf("device is opened\r\n");
```

```
}
```

```
else
```

```
{    //closed  
    printf("device is closed (0x%X)\r\n", AX_GetLastError());
```

```
}
```

2.6. AX_Close

Summary

Close serial port of CAN-board.

Definition

BOOL AX_Close (void)

Parameters

None

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;
bRst = AX_Close();
if (bRst)
{
    //success
    printf("close success\r\n");
}
else
{
    //failure
    printf("close failure (0x%X)\r\n", AX_GetLastError());
}
```


3. CANBus information function

3.1. AX_GetModel

Summary

Get model name of CAN-board.

Definition

BOOL AX_GetModel(char* pModel)

Parameters

pModel out Model name of CAN-board

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;
char cModel[512];
memset(cModel, 0x0, sizeof(cModel));
bRst = AX_GetModel(cModel);
if (bRst)
{
    //success
    printf("Model=%s\r\n", cModel);
}
else
{
    //failure
    printf("get model name failure (0x%X)\r\n", AX_GetLastError());
}
```

3.2. AX_GetUUID

Summary

Get UUID of CAN-board.

Definition

BOOL AX_GetUUID(char* pUUID)

Parameters

pUUID out UUID of CAN-board

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;
char cUUID[512];
memset(cUUID, 0x0, sizeof(cUUID));
bRst = AX_GetUUID(cUUID);
if (bRst)
{
    //success
    printf("UUID=%s\r\n", cUUID);
}
else
{
    //failure
    printf("get UUID failure (0x%X)\r\n", AX_GetLastError());
}
```

3.3. AX_GetSN

Summary

Get serial number of CAN-board.

Definition

BOOL AX_GetSN(char* pSN)

Parameters

pSN out Serial number of CAN-board

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;
char cSN[512];
memset(cSN, 0x0, sizeof(cSN));
bRst = AX_GetSN(cSN);
if (bRst)
{
    //success
    printf("SN=%s\r\n", cSN);
}
else
{
    //failure
    printf("get SN failure (0x%X)\r\n", AX_GetLastError());
}
```

3.4. AX_GetManufacturer

Summary

Get manufacturer of CAN-board.

Definition

BOOL AX_GetManufacturer(char* pManufacturer)

Parameters

pManufacturer out Manufacturer of CAN-board

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;
char cManufacturer[512];
memset(cManufacturer, 0x0, sizeof(cManufacturer));
bRst = AX_GetManufacturer(cManufacturer);
if (bRst)
{
    //success
    printf("Manufacturer=%s\r\n", cManufacturer);
}
else
{
    //failure
    printf("get manufacturer failure (0x%X)\r\n", AX_GetLastError());
}
```

3.5. AX_GetProductionDate

Summary

Get production date of CAN-board.

Definition

BOOL AX_GetProductionDate(char* pDate)

Parameters

pDate out Production date of CAN-board

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;
char cDate[512];
memset(cDate, 0x0, sizeof(cDate));
bRst = AX_GetProductionDate(cDate);
if (bRst)
{
    //success
    printf("Production date=%s\r\n", cDate);
}
else
{
    //failure
    printf("get production date failure (0x%X)\r\n", AX_GetLastError());
}
```

3.6. AX_GetVersion

Summary

Get firmware version of CAN-board.

Definition

BOOL AX_GetVersion(char* pVersion)

Parameters

pVersion out Firmware version of CAN-board

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;
char cVersion[512];
memset(cVersion, 0x0, sizeof(cVersion));
bRst = AX_GetVersion(cVersion);
if (bRst)
{
    //success
    printf("fw ver=%s\r\n", cVersion);
}
else
{
    //failure
    printf("get fw version failure (0x%X)\r\n", AX_GetLastError());
}
```

4. CANopen basic function

4.1. AX_SetCommTimeout

Summary

Set timeout of communication.

Definition

```
int AX_SetCommTimeout(DWORD iTimeout)
```

Parameters

iTimeout in timeout of communication (ms)

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;
```

```
bRst = AX_SetCommTimeout(500);      // 500ms
```

```
if (bRst)
```

```
{      // success
```

```
    printf("set timeout success\r\n");
```

```
}
```

```
else
```

```
{      // failure
```

```
    printf("set timeout failure (0x%X)\r\n", AX_GetLastError());
```

```
}
```

4.2. AX_InitCANopen

Summary

Initializes the CANopen Master API.

Definition

BOOL AX_InitCANopen(int iDevNum, int iBitrate, int iNodeID, BOOL bTermination)

Parameters

iDevNum	in	Selection of the CAN line to be use (0)
iBitrate	in	Number of the bitrate table of CAN to be use The following values are permitted: (see 10.2) AX_CAN_BITRATE_5K AX_CAN_BITRATE_10K AX_CAN_BITRATE_20K AX_CAN_BITRATE_40K AX_CAN_BITRATE_50K AX_CAN_BITRATE_80K AX_CAN_BITRATE_100K AX_CAN_BITRATE_125K AX_CAN_BITRATE_200K AX_CAN_BITRATE_250K AX_CAN_BITRATE_400K AX_CAN_BITRATE_500K AX_CAN_BITRATE_640K AX_CAN_BITRATE_800K AX_CAN_BITRATE_1000K
iNodeID	in	Node ID of the CANopen Master API between 1 to 127
bTermination	in	Enable/Disable termination state

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;
int iDevNum=0;           // CANbus number
int iBitrate=AX_CAN_BITRATE_1000K; // 1M bitrate
int iNodeID=1;          // Node ID=1
BOOL bTermination=TRUE; // enable termination state
bRst = AX_InitCANopen(iDevNum, iBitrate, iNodeID, bTermination);
if (bRst)
{ //success
    printf("Initial CANopen success\r\n");
}
```



```
}  
else  
{ //failure  
  printf("Initial CANopen failure (0x%X)\r\n", AX_GetLastError());  
}
```

4.3. AX_ReleaseCANOpen

Summary

Releases CANOpen Master API.

Definition

BOOL AX_ReleaseCANOpen(void)

Parameters

None

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;
```

```
bRst = AX_ReleaseCANOpen();
```

```
if (bRst)
```

```
{ //success
```

```
    printf("release CANOpen success\r\n");
```

```
}
```

```
else
```

```
{ //failure
```

```
    printf("release CANOpen failure (0x%X)\r\n", AX_GetLastError());
```

```
}
```

4.4. AX_IsInitCANopen

Summary

Gets a value indicating the initialization or release status of the CANopen.

Definition

BOOL AX_IsInitCANopen(void)

Parameters

None

Return value

TRUE means the CANopen is initialization, FALSE means the CANopen is release.

Example

```
BOOL bRst;
bRst = AX_IsInitCANopen();
if (bRst)
{
    //initialization
    printf("CANopen is initialization\r\n");
}
else
{
    //release
    printf("CANopen is release\r\n");
}
```

4.5. AX_SetEventCallback

Summary

Register callback function after trigger event.

Definition

BOOL AX_SetEventCallback(int iIndex, PCANEVENT pFunCallback)

Parameters

iIndex	in	Index of the event table
		The following values are permitted: (see 10.3)
		AX_EVT_NMT_NODE_GAURDING
		AX_EVT_NMT_HEARTBEAT
		AX_EVT_SYNC_WRITE
		AX_EVT_TIME_WRITE
		AX_EVT_EMCY_WRITE
		AX_EVT_PDO_RX
pFunCallback	in	Callback function
		typedef int (*PCANEVENT) (void *pParam)

Return value

TRUE means success and FALSE means failure.

Example

```
int EventHeartbeat(void *pParam);
BOOL bRst;
bRst = AX_SetEventCallback(AX_EVT_NMT_HEARTBEAT, EventHeartbeat);
if (bRst)
{
    //success
    printf("added new node success\r\n");
}
else
{
    //failure
    printf("added new node failure (0x%X)\r\n", AX_GetLastError());
}

// heartbeat error
int EventHeartbeat(long lParam)
{
    printf("Heartbeat error, Node ID=0x%x\r\n", (int)lParam);
}
```

5. CANopen NMT function

5.1. AX_NMT_SearchNode

Summary

Checks CANopen-device is available in the network with the specified node ID.

Definition

```
BOOL AX_NMT_SearchNode(int iNodeID)
```

Parameters

iNodeID in Node ID of the CANopen device to be searched for (1-127)

Return value

TRUE means the remote node is existed, FALSE means the remote node isn't existed.

Example

```
BOOL bRst;  
int iNodeID=2;  
bRst = AX_NMT_SearchNode(iNodeID);  
if (bRst)  
{    //existed  
    printf("remote node is existed\r\n");  
}  
else  
{    //not existed  
    printf("remote node is not existed\r\n");  
}
```

5.2. AX_NMT_AddNode

Summary

Added and registered a new node into node table.

Definition

BOOL AX_NMT_AddNode(int iNodeID, int iType, int iTime, int iLifeTime)

Parameters

iNodeID	in	Node ID of the CANopen device (1-127)
iType	in	Definition of the monitoring mechanism applicable The following values are permitted: (see 10.4) AX_RMN_TYPE_GUARDING AX_RMN_TYPE_HEARTBEAT
iTime	in	Guardtime in milliseconds 0: Disable guarded
iLifeTime	in	Defines the number of unsuccessful attempts at a Guard-request by the Master to be permitted (1-255)

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;
int iNodeID=2; // Node ID
int iNodeType=AX_RMN_TYPE_GUARDING; // Guarding
int iNodeTime=500; // 500ms
int iLifeTimeFactor=1; // 1 times
bRst = AX_NMT_AddNode(iNodeID, iNodeType, iNodeTime, iLifeTimeFactor);
if (bRst)
{ //success
    printf("added new node success\r\n");
}
else
{ //failure
    printf("added new node failure (0x%X)\r\n", AX_GetLastError());
}
```

5.3. AX_NMT_DelNode

Summary

Remove a node from node table.

Definition

```
BOOL AX_NMT_DelNode(int iNodeID)
```

Parameters

iNodeID in Node ID of the CANopen device (1-127)

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;
int iNodeID=2;      // Node ID
bRst = AX_NMT_DelNode(iNodeID);
if (bRst)
{      //success
    printf("deleted remote node success\r\n");
}
else
{      //failure
    printf("deleted remote node failure (0x%X)\r\n", AX_GetLastError());
}
}
```

5.4. AX_NMT_GetNodeInfo

Summary

Get node information from node table.

Definition

BOOL AX_NMT_GetNodeInfo(int iNodeID, int* pType, int* pTime, int* pLifeTime)

Parameters

iNodeID	in	Node ID of the CANopen device (1-127)
pType	out	Definition of the monitoring mechanism applicable The following values are possible: (see 10.4) AX_RMN_TYPE_GUARDING AX_RMN_TYPE_HEARTBEAT
pTime	out	Guardtime in milliseconds 0: Disable guarded
pLifeTime	out	Defines the number of unsuccessful attempts at a Guard-request by the Master to be permitted (1-255)

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;
int iNodeID=2;    // Node ID
int iType=0;
int iTime=0;
int iLifeTimeFactor=0;
bRst = AX_NMT_GetNodeInfo(iNodeID, &iType, &iTime, &iLifeTimeFactor);
if (bRst)
{
    //success
    printf("NodeID=%d, Type=%d, GuardTime=%d, LifeTime=%d\r\n",
           iNodeID, iType, iTime, iLifeTimeFactor);
}
else
{
    //failure
    printf("Failure to get information from remote node (0x%X)\r\n",
           AX_GetLastError());
}
```


5.5. AX_NMT_GetNodeState

Summary

Get node state from remote node.

Definition

BOOL AX_NMT_GetNodeState(int iNodeID, int* pState)

Parameters

iNodeID	in	Node ID of the CANopen device (1-127)
pState	out	Current state of the remote node

The following values are possible: **(see 10.6)**

- AX_DEV_STATE_NONE
- AX_DEV_STATE_BOOTUP
- AX_DEV_STATE_STOPED
- AX_DEV_STATE_OPERATIONAL
- AX_DEV_STATE_PREOPERATIONAL

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;
int iNodeID=2;    // Node ID
int iState=AX_DEV_STATE_NONE;
bRst = AX_NMT_GetNodeState(iNodeID, &iState);
if (bRst)
{
    //success
    if (iState == AX_DEV_STATE_BOOTUP)
        printf("device state : boot-up\r\n");
    else if (iState == AX_DEV_STATE_STOPED)
        printf("device state : stop\r\n");
    else if (iState == AX_DEV_STATE_OPERATIONAL)
        printf("device state : operational\r\n");
    else if (iState == AX_DEV_STATE_PREOPERATIONAL)
        printf("device state : pre-operational\r\n");
    else
        printf("device state : unknow\r\n");
}
else
{
    //failure
    printf("Failure to get status from remote node (0x%X)\r\n", AX_GetLastError());
}
```

5.6. AX_NMT_StartNode

Summary

Transfer a remote node into OPERATIONAL state.

Definition

BOOL AX_NMT_StartNode(int iNodeID)

Parameters

iNodeID in Node ID of the CANopen device (1-127)

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;
int iNodeID=2;      // Node ID
bRst = AX_NMT_StartNode(iNodeID);
if (bRst)
{      //success
    printf("start remote node success\r\n");
}
else
{      //failure
    printf("start remote node failure (0x%X)\r\n", AX_GetLastError());
}
```

5.7. AX_NMT_StopNode

Summary

Transfer a remote node into STOPPED state.

Definition

BOOL AX_NMT_StopNode(int iNodeID)

Parameters

iNodeID in Node ID of the CANopen device (1-127)

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;
int iNodeID=2;      // Node ID
bRst = AX_NMT_StopNode(iNodeID);
if (bRst)
{      //success
    printf("stop remote node success\r\n");
}
else
{      //failure
    printf("stop remote node failure (0x%X)\r\n", AX_GetLastError());
}
```

5.8. AX_NMT_EnterPreOper

Summary

Transfer a remote node into PRE-OPERATIONAL state.

Definition

BOOL AX_NMT_EnterPreNode(int iNodeID)

Parameters

iNodeID in Node ID of the CANopen device (1-127)

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;
int iNodeID=2;      // Node ID
bRst = AX_NMT_EnterPreNode(iNodeID);
if (bRst)
{      //success
    printf("Success to enter pre-operational of remote node\r\n");
}
else
{      //failure
    printf("Failure to enter pre-operational of remote node (0x%X)\r\n",
          AX_GetLastError());
}
}
```

5.9. AX_NMT_ResetComm

Summary

Reset the communication profile of a remote node.

Definition

BOOL AX_NMT_ResetComm(int iNodeID)

Parameters

iNodeID in Node ID of the CANopen device (1-127)

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;
int iNodeID=2;      // Node ID
bRst = AX_NMT_ResetComm(iNodeID);
if (bRst)
{      //success
    printf("Success to reset communication of remote node\r\n");
}
else
{      //failure
    printf("Failure to reset communication of remote node (0x%X)\r\n",
        AX_GetLastError());
}
```

5.10. AX_NMT_ResetNode

Summary

Reset the application of a remote node.

Definition

BOOL AX_NMT_ResetNode(int iNodeID)

Parameters

iNodeID in Node ID of the CANopen device (1-127)

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;
int iNodeID=2;      // Node ID
bRst = AX_NMT_ResetNode(iNodeID);
if (bRst)
{      //success
    printf("reset remote node success\r\n");
}
else
{      //failure
    printf("reset remote node failure (0x%X)\r\n" , AX_GetLastError());
}
```

6. CANopen SDO function

6.1. AX_SDO_GetObj

Summary

Read the Object Dictionary entry from a remote node.

Definition

```
BOOL AX_SDO_GetObj(int iNodeID, int iMode, int ildx, int iSubIdx, int* pLen,  
                  char* pData, UINT *pAbortCode)
```

Parameters

iNodeID	in	Node ID of the CANopen device (1-127)
iMode	in	Definition of the SDO-transmission protocol The following values are permitted: (see 10.9) AX_SDO_MODE_NORMAL AX_SDO_MODE_BLOCK
ildx	in	Index of the object dictionary entry
iSubIdx	in	Sub-index of the object dictionary entry
pLen	in/out	(in) pData buffer size (out) Read size
pData	out	Data of the object dictionary entry
pAbortCode	out	Possible Abort-Code of the SDO-Transfer In case of an abort, AX_ERR_SDO_ABORT is returned as return value.

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;  
char cData[512]; // buffer  
int iNodeID=2; // Node ID  
int iMode= AX_SDO_MODE_NORMAL; // SDO mode  
int ildx=0x1000; // Index of OD  
int iSubIdx=0x00; // Sub-index of OD  
int iLen=sizeof(cData); // length  
UINT iAbort=0; // abort code  
memset(cData, 0x0, sizeof(cData));  
bRst = AX_SDO_GetObj(iNodeID, iMode, ildx, iSubIdx, &iLen, cData, &iAbort);  
if (bRst)  
{ //success  
    printf("Success to get SDO from remote node\r\n");  
}  
else
```

```
{ //failure
  printf("Failure to get SDO from remote node (0x%X)\r\n", AX_GetLastError());
}
```


6.2. AX_SDO_SetObj

Summary

Write data into an object dictionary entry of a remote node.

Definition

```
BOOL AX_SDO_GetObj(int iNodeID, int iMode, int ildx, int iSubIdx, int iLen,  
                  char* pData, UINT *pAbortCode)
```

Parameters

iNodeID	in	Node ID of the CANopen device (1-127)
iMode	in	Definition of the SDO-transmission protocol The following values are permitted: (see 10.9) AX_SDO_MODE_NORMAL AX_SDO_MODE_BLOCK
ildx	in	Index of the object dictionary entry
iSubIdx	in	Sub-index of the object dictionary entry
iLen	in	pData buffer size
pData	in	Data of the object dictionary entry
pAbortCode	out	Possible Abort-Code of the SDO-Transfer In case of an abort, AX_ERR_SDO_ABORT is returned as return value.

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;  
char cData[512]; // buffer  
int iNodeID=2; // Node ID  
int iMode= AX_SDO_MODE_NORMAL; // SDO mode  
int ildx=0x1017; // Index of OD  
int iSubIdx=0x00; // Sub-index of OD  
UINT iAbort=0; // abort code  
memset(cData, 0x0, sizeof(cData));  
cData[0] = (500&0xFF00)>>8;  
cData[1] = 500&0xFF;  
bRst = AX_SDO_SetObj(iNodeID, iMode, ildx, iSubIdx, 2, cData, &iAbort);  
if (bRst)  
{ //success  
    printf("Success to set SDO into remote node\r\n");  
}  
else  
{ //failure
```

```
printf("Failure to set SDO into remote node (0x%X)\r\n", AX_GetLastError());  
}
```

7. CANopen PDO function

7.1. AX_PDO_AddObj

Summary

Add a new PDO into PDO table.

Definition

BOOL AX_PDO_AddObj(int iNodeID, int iPDONo, int iPDOType, int iPDOMode,
int iSyncCount, int iLen, int iCANID)

Parameters

iNodeID	in	Node ID of the CANopen device (1-127)
iPDONo	in	Number of PDO (1-16)
iPDOType	in	Transmission direction of the PDO from point of view The following values are permitted: (see 10.7) AX_PDO_TYPE_TX AX_PDO_TYPE_RX
iPDOMode	in	Mode of PDO The following values are permitted: (see 10.8) AX_PDO_MODE_ASYNC AX_PDO_MODE_SYNC
iSyncCount	in	Reserved
iLen	in	Data length of PDO
iCANID	in	Identifier of the CAN-object used by the PDO The following values are permitted: (see 10.5) AX_CANID_MASTER_TPDO1 AX_CANID_MASTER_RPDO1 AX_CANID_MASTER_TPDO2 AX_CANID_MASTER_RPDO2 AX_CANID_MASTER_TPDO3 AX_CANID_MASTER_RPDO3 AX_CANID_MASTER_TPDO4 AX_CANID_MASTER_RPDO4

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;  
int iNodeID=2;           // Node ID  
int iPDONo=1;           // PDO no  
int iPDOType=AX_PDO_TYPE_RX; // rx type  
int iPDOMode=AX_PDO_MODE_ASYNC; // async mode
```

```
int iLen=1;                // length
int iCANID=AX_CANID_MASTER_RPDO1; // CANID
// added RPDO1 object
bRst = AX_PDO_AddObj(iNodeID, iPDONo, iPDOType, iPDOMode, 0, iLen, iCANID);
if (bRst)
{ //success
    printf("Success to add PDO information into PDO table\r\n");
}
else
{ //failure
    printf("Failure to add PDO information into PDO table (0x%X)\r\n",
        AX_GetLastError());
}
```

7.2. AX_PDO_DelObj

Summary

Delete PDO from PDO table.

Definition

BOOL AX_PDO_DelObj(int iNodeID, int iPDONo, int iPDOType)

Parameters

iNodeID	in	Node ID of the CANopen device (1-127)
iPDONo	in	Number of PDO (1-16)
iPDOType	in	Transmission direction of the PDO from point of view

The following values are permitted: **(see 10.7)**

AX_PDO_TYPE_TX
AX_PDO_TYPE_RX

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;
Int iNodeID=2;           // node id
int iPDONo=1;           // PDO no
int iPDOType=AX_PDO_TYPE_RX; // rx type
// delete RPDO1 object
bRst = AX_PDO_DelObj(iNodeID, iPDONo, iPDOType);
if (bRst)
{ //success
    printf("Success to delete PDO information from PDO table\r\n");
}
else
{ //failure
    printf("Failure to delete PDO information from PDO table (0x%X)\r\n",
        AX_GetLastError());
}
```

7.3. AX_PDO_GetObjInfo

Summary

Get PDO information from PDO table.

Definition

```
BOOL AX_PDO_GetObjInfo(int iNodeID, int iPDONo, int iPDOType,  
                       int* pPDOMode, int* pSyncCount, int* pLen, int* pCANID)
```

Parameters

iNodeID	in	Node ID of the CANopen device (1-127)
iPDONo	in	Number of PDO (1-16)
iPDOType	in	Transmission direction of the PDO from point of view The following values are permitted: (see 10.7) AX_PDO_TYPE_TX AX_PDO_TYPE_RX
pPDOMode	out	Mode of PDO The following values are possible: (see 10.8) AX_PDO_MODE_ASYNC AX_PDO_MODE_SYNC
pSyncCount	out	Reserved
pLen	out	Data length of PDO
pCANID	out	Identifier of the CAN-object used by the PDO The following values are possible: (see 10.5) AX_CANID_MASTER_TPDO1 AX_CANID_MASTER_RPDO1 AX_CANID_MASTER_TPDO2 AX_CANID_MASTER_RPDO2 AX_CANID_MASTER_TPDO3 AX_CANID_MASTER_RPDO3 AX_CANID_MASTER_TPDO4 AX_CANID_MASTER_RPDO4

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;  
int iNodeID=0;           // Node ID  
int iPDONo=1;           // PDO number  
int iPDOType= AX_PDO_TYPE_RX; // rx type  
int iPDOMode=0;  
int iSyncCount=0;
```

```
int iLen=0;
int iCANID=0;                // CANID
// Get RPDO1 object info
bRst = AX_PDO_GetObjInfo(iNodeID, iPDONo, iPDOType,
                        &iPDOMode, &iSyncCount, &iLen, &iCANID);

if (bRst)
{ //success
    printf("Success to get PDO information from PDO table\r\n");
}
else
{ //failure
    printf("Failure to get PDO information from PDO table (0x%X)\r\n",
        AX_GetLastError());
}
```

7.4. AX_PDO_GetUpdObj

Summary

Read the updated data of a PDO received from the RPDO-queue.

Definition

```
BOOL AX_PDO_GetUpdObj(int* pNodeID, int* pPDONo,  
                      int* pLen, char* pData, int *pSyncCount)
```

Parameters

iNodeID	out	Node ID of the CANopen device (1-127)
iPDONo	out	Number of PDO (1-16)
pLen	in/out	(in) Data length of pData (1-8) (out) Read size
pData	out	PDO data
pSyncCount	out	Reserved

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;  
char cData[1];  
int iNodeID=0;  
int iPDONo=0;  
int iSyncCount=0;  
int iLen=sizeof(cData); // length  
memset(cData, 0x0, sizeof(cData));  
// get RPDO data  
bRst = AX_PDO_GetObj(&iNodeID, &iPDONo, &iLen, cData, &iSyncCount);  
if (bRst)  
{ //success  
    printf("Success to get RPDO\r\n");  
}  
else  
{ //failure  
    printf("No RPDO update\r\n");  
}
```


7.5. AX_PDO_GetObj

Summary

Read the data of a PDO received from the RPDO-queue.

Definition

```
BOOL AX_PDO_GetObj(int iNodeID, int iPDONo,  
                  int* pLen, char* pData, int *pSyncCount)
```

Parameters

iNodeID	in	Node ID of the CANopen device (1-127)
iPDONo	in	Number of PDO (1-16)
pLen	in/out	(in) Data length of pData (1-8) (out) Read size
pData	out	PDO data
pSyncCount	out	Reserved

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;  
char cData[1];  
int iNodeID=2;    // Node id  
int iPDONo=1;    // PDO number  
int iSyncCount=0;  
int iLen=sizeof(cData); // length  
memset(cData, 0x0, sizeof(cData));  
// get RPDO1 data  
bRst = AX_PDO_GetObj(iNodeID, iPDONo, &iLen, cData, &iSyncCount);  
if (bRst)  
{ //success  
    printf("Success to get PDO from remote node\r\n");  
}  
else  
{ //failure  
    printf("Failure to get PDO from remote node (0x%X)\r\n", AX_GetLastError());  
}
```

7.6. AX_PDO_SetObj

Summary

Write the data of a PDO transmitted to the TPDO-queue.

Definition

BOOL AX_PDO_SetObj(int iNodeID, int iPDONo, int iLen, char* pData)

Parameters

iNodeID	in	Node ID of the CANopen device (1-127)
iPDONo	in	Number of PDO (1-16)
iLen	in	Data length of pData (1-8)
pData	in	PDO data

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;
char cData[1];
int iNodeID=2;          // node id
int iPDONo=1;          // PDO number
int iLen=sizeof(cData); // length
cData[0]=0xFF;
bRst = AX_PDO_SetObj(iNodeID, iPDONo, iLen, cData);
if (bRst)
{ //success
    printf("Success to set PDO into remote node\r\n");
}
else
{ //failure
    printf("Failure to set PDO into remote node (0x%X)\r\n", AX_GetLastError());
}
```

8. CANopen SYNC function

8.1. AX_SYNC_Enable

Summary

Enable synchronization.

Definition

BOOL AX_SYNC_Enable(void)

Parameters

None

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;
bRst = AX_SYNC_Enable();
if (bRst)
{
    //success
    printf("Success to enable sync object\r\n");
}
else
{
    //failure
    printf("Failure to enable sync object(0x%X)\r\n", AX_GetLastError());
}
```

8.2. AX_SYNC_Disable

Summary

Disable synchronization.

Definition

BOOL AX_SYNC_Disable(void)

Parameters

None

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;
```

```
bRst = AX_SYNC_Disable();
```

```
if (bRst)
```

```
{    //success
```

```
    printf("Success to disable sync object\r\n");
```

```
}
```

```
else
```

```
{    //failure
```

```
    printf("Failure to disable sync object(0x%X)\r\n", AX_GetLastError());
```

```
}
```

8.3. AX_SYNC_GetConfig

Summary

Get configuration of synchronization.

Definition

BOOL AX_SYNC_GetConfig(PUINT32 pPeriod, PUINT32 pWindows, int* pCount)

Parameters

pPeriod	out	The cycle time between sync object (milliseconds)
pWindows	out	Reserved
pCount	out	Maximum value of the sync counter

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;
UINT32 iPeriod=0;
UINT32 iWindows=0;
int iCount=0;
bRst = AX_SYNC_GetConfig(&iPeriod, &iWindows, &iCount);
if (bRst)
{
    //success
    printf("Success to get configuration of synchronization\r\n");
}
else
{
    //failure
    printf("Failure to get configuration of synchronization (0x%X)\r\n",
        AX_GetLastError());
}
```

8.4. AX_SYNC_SetConfig

Summary

Set configuration of synchronization.

Definition

BOOL AX_SYNC_SetConfig(UINT32 iPeriod, UINT32 iWindows, int iCount)

Parameters

iPeriod	in	The cycle time between sync object (milliseconds)
iWindows	in	Reserved
iCount	in	Maximum value of the sync counter (2-240)

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;
UINT32 iPeriod=3000; // 3 sec
UINT32 iWindows=0;
int iCount=2; // max count
bRst = AX_SYNC_SetConfig(iPeriod, iWindows, iCount);
if (bRst)
{ //success
    printf("Success to set configuration of synchronization\r\n");
}
else
{ //failure
    printf("Failure to set configuration of synchronization (0x%X)\r\n",
        AX_GetLastError());
}
```

9. CANopen TIME function

9.1. AX_TIME_Enable

Summary

Enable timestamp.

Definition

BOOL AX_TIME_Enable(void)

Parameters

None

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;
bRst = AX_TIME_Enable();
if (bRst)
{
    //success
    printf("Success to enable timestamp object\r\n");
}
else
{
    //failure
    printf("Failure to enable timestamp object(0x%X)\r\n", AX_GetLastError());
}
```

9.2. AX_SYNC_Disable

Summary

Disable timestamp.

Definition

BOOL AX_TIME_Disable(void)

Parameters

None

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;
```

```
bRst = AX_TIME_Disable();
```

```
if (bRst)
```

```
{    //success
```

```
    printf("Success to disable timestamp object\r\n");
```

```
}
```

```
else
```

```
{    //failure
```

```
    printf("Failure to disable timestamp object(0x%X)\r\n", AX_GetLastError());
```

```
}
```


9.3. AX_TIME_GetConfig

Summary

Get configuration of timestamp.

Definition

BOOL AX_TIME_GetConfig(PUINT16 pDays, PUINT32 pMSec, PUINT32 pPeriod)

Parameters

pDays	out	Days since 1984/1/1
pMSec	out	Milliseconds after midnight
pPeriod	out	The cycle time between timestamp object (milliseconds)

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;
UINT16 iDays=0;
UINT32 iMSec=0;
UINT32 iPeriod=0;
int iCount=0;
bRst = AX_TIME_GetConfig(&iDays, &iMSec, &iPeriod);
if (bRst)
{
    //success
    printf("Success to get configuration of timestamp\r\n");
}
else
{
    //failure
    printf("Failure to get configuration of timestamp (0x%X)\r\n",
        AX_GetLastError());
}
```

9.4. AX_TIME_SetConfig

Summary

Set configuration of timestamp.

Definition

BOOL AX_TIME_SetConfig(UINT16 iDays, UINT32 iMSec, UINT32 iPeriod)

Parameters

iDays	in	Days since 1984/1/1
iMSec	in	Milliseconds after midnight
iPeriod	in	The cycle time between timestamp object (milliseconds)

Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;
UINT16 iDays=11315;      // 2015/1/1
UINT32 iMSec=36000000;  // 10:00
UINT32 iPeriod=1000;    // 1000ms
bRst = AX_TIME_SetConfig(iDays, iMSec, iPeriod);
if (bRst)
{
    //success
    printf("Success to set configuration of timestamp \r\n");
}
else
{
    //failure
    printf("Failure to set configuration of timestamp (0x%X)\r\n",
        AX_GetLastError());
}
```

10. CANopen EMCY function

10.1. AX_EMCY_GetObj

Summary

Read the data of a EMCY object received from the EMCY-queue.

Definition

BOOL AX_EMCY_GetObj(int* pNodeID, int* pErrCode, int* pErrReg, char* pErrData)

Parameters

pNodeID	out	Number of the node that has issued the error message
pErrCode	out	Error code of the error message
pErrReg	out	Error register of the error message
pErrData	out	Error data of the error message


Return value

TRUE means success and FALSE means failure.

Example

```
BOOL bRst;
int iNodeID=0;          // Node ID
int iErrCode=0;        // Error code
int iErrReg=0;         // Error register
char cErrData[8];      // Error data
memset(cErrData, 0x0, sizeof(cErrData));
bRst = AX_EMCY_GetObj(&iNodeID, &iErrCode, &iErrReg, cErrData);
if (bRst)
{
    //success
    printf("Success to get EMCY object from remote node\r\n");
}
else
{
    //failure
    printf("Failure to get EMCY object from remote node (0x%X)\r\n",
           AX_GetLastError());
}
```

11. Typical sequence of function calls



12. Appendix

12.1. Appendix - Error code list

Name	Value	Description
AX_ERR_NONE	0x0000	No error
AX_ERR_BUSY	0x0001	Function busy
AX_ERR_PARA	0x0002	Parameters error
AX_ERR_CONNECTED	0x0010	Device has been connected
AX_ERR_DISCONNECTED	0x0011	Device has been disconnected
AX_ERR_QUEUEEMPTY	0x0012	Queue empty
AX_ERR_UNINITIALIZED	0x0013	CANopen has not been initialized
AX_ERR_THREADFAIL	0x0014	Resume thread error
AX_ERR_CAN_OPENED	0x0020	CAN-port has been opened
AX_ERR_CAN_CLOSED	0x0021	CAN-port has been closed
AX_ERR_CAN_BITRATE	0x0022	Set bitrate error of CAN
AX_ERR_CAN_CONFIG	0x0023	Set configuration error of CAN
AX_ERR_CAN_TERMIN	0x0024	Set termination error of CAN
AX_ERR_CAN_ID	0x0025	Set CAN-ID error of CAN
AX_ERR_CAN_MASK	0x0026	Set CAN-mask error of CAN
AX_ERR_CAN_TX	0x0027	Send message error of CAN
AX_ERR_CAN_RX	0x0028	Receive message error of CAN
AX_ERR_CAN_TIMEOUT	0x0029	Response timeout of CAN
AX_ERR_NMT_NODEEXIST	0x0030	NMT-node is exist
AX_ERR_NMT_NODENOTEXIST	0x0031	NMT-node is not exist
AX_ERR_PDO_TIMEOUT	0x0040	PDO timeout
AX_ERR_PDO_OBJEXIST	0x0041	Object is exist in PDO list
AX_ERR_PDO_OBJNOTEXIST	0x0042	Object is not exist in PDO list
AX_ERR_PDO_CANIDEXIST	0x0043	CANID is exist of object in PDO list
AX_ERR_SDO_TIMEOUT	0x0050	SDO timeout
AX_ERR_SDO_ABORT	0x0051	SDO abort
AX_ERR_SDO_FORMAT	0x0052	SDO format error
AX_ERR_EVENT_SYNC	0x1000	Sync object error
AX_ERR_EVENT_PDO	0x1001	Sync PDO error
AX_ERR_EVENT_TIME	0x1002	Time object error

12.2. Appendix - CANbus bitrate list

Name	Value	Description
AX_CAN_BITRATE_5K	0x0	5k
AX_CAN_BITRATE_10K	0x1	10k
AX_CAN_BITRATE_20K	0x2	20k
AX_CAN_BITRATE_40K	0x3	40k
AX_CAN_BITRATE_50K	0x4	50k
AX_CAN_BITRATE_80K	0x5	80k
AX_CAN_BITRATE_100K	0x6	100k
AX_CAN_BITRATE_125K	0x7	125k
AX_CAN_BITRATE_200K	0x8	200k
AX_CAN_BITRATE_250K	0x9	250k
AX_CAN_BITRATE_400K	0xA	400k
AX_CAN_BITRATE_500K	0xB	500k
AX_CAN_BITRATE_640K	0xC	640k
AX_CAN_BITRATE_800K	0xD	800k
AX_CAN_BITRATE_1000K	0xE	1000k

12.3. Appendix - Event list

Name	Value	Description	Return value
AX_EVT_NMT_NODE_GAURDING	0x0101	Guarding error	INT(Node ID)
AX_EVT_NMT_HEARTBEAT	0x0102	Heartbeat error	INT(Node ID)
AX_EVT_EMCY	0x0401	EMCY event	NULL
AX_EVT_PDO_RX	0x0501	RPDO event	NULL
AX_EVT_ERROR	0xFF01	Thread error event	INT(Error code)

12.4. Appendix - Monitoring type list of NMT

Name	Value	Description
AX_RMN_TYPE_GUARDING	0x0001	Guarding
AX_RMN_TYPE_HEARTBEAT	0x0002	Heartbeat

12.5. Appendix - CANID list for Master of NMT

Name	Value	Description
AX_CANID_MASTER_RPDO1	0x180	RPDO1 of CANID
AX_CANID_MASTER_TPDO1	0x200	TPDO1 of CANID
AX_CANID_MASTER_RPDO2	0x280	RPDO2 of CANID
AX_CANID_MASTER_TPDO2	0x300	TPDO2 of CANID
AX_CANID_MASTER_RPDO3	0x380	RPDO3 of CANID
AX_CANID_MASTER_TPDO3	0x400	TPDO3 of CANID
AX_CANID_MASTER_RPDO4	0x480	RPDO4 of CANID
AX_CANID_MASTER_TPDO4	0x500	TPDO4 of CANID

12.6. Appendix - Status list of NMT

Name	Value	Description
AX_DEV_STATE_NONE	0x00	Un-know
AX_DEV_STATE_BOOTUP	0x01	Boot-up
AX_DEV_STATE_STOPPED	0x02	Stopped
AX_DEV_STATE_OPERATIONAL	0x03	Operational
AX_DEV_STATE_PREOPERATIONAL	0x04	Pre-operational

12.7. Appendix - Transmission type list of PDO

Name	Value	Description
AX_PDO_TYPE_TX	0x01	PDO tx
AX_PDO_TYPE_RX	0x02	PDO rx

12.8. Appendix - Synchronous mode list of PDO

Name	Value	Description
AX_PDO_MODE_ASYNC	0x00	Synchronous mode
AX_PDO_MODE_SYNC	0x01	Asynchronous mode

12.9. Appendix - Transmission protocol list of SDO

Name	Value	Description
AX_SDO_MODE_NORMAL	0x00	Use of the normal transfer protocol
AX_SDO_MODE_BLOCK	0x01	Use of the block transfer protocol